



ADDENDUM TO TRAINING DOCUMENTS.

This Addendum Document will contain any updates, corrections or clarifications to the Training Documents.

Addendum One to the Training Video and Training Document “Helix Platform Setup”.

The first Training Document “Helix Platform Setup” was created assuming the Helipad would accompany the Platform. If you did not purchase a Helipad, which is used for local control of the Platform, Then you will need to follow this addendum in setting up your Helix Platform.

Setup your Helix Platform as explained in “Helix Platform Setup” but stop when it tells you to “activate and test the Helipad”, instead go to page-8 to test your Key fob. After you have tested your Key fob, continue your setup by going to Training Document “Sensor Testing “.

Addendum Two to the Training Video and Training Document “Helix Platform Setup”.

The Helix Key fob RE600 comes to you already programed to your system and ready to use. There is not a battery tab that you have to remove as stated in the training document “Helix Platform Setup”.

Addendum Three to the Training Video and Training Document “Helix Platform Setup”.

Addendum One to the Training Video and Training Document “Customer Account Part-One”.

TRAINING DOCUMENT “CUSTOMER ACCOUNT PART-ONE”

SLIDE 1 of 1

The **SILENT ICON**, IF HIGHLIGHTED, WILL SURPRESS THE BEEPING DURING COUNTDOWN TO ARM.

The **DELAY ICON**, IF HIGHLIGHTED, WILL CANCEL THE ENTRY DELAY TIME AND SET THE ALARM OFF IMMEDIATELY IF A NORMAL ENTRY DOOR IS OPENED.

The **REFRESH** Button will reload the Helix Platform Settings onto your screen.

Addendum One to the Training Video and Training Document “Customer Account Part-Two”.

“CUSTOMER ACCOUNT TWO”

SLIDE 1 of 3

Account

- Account Details
- Property Details
- Contacts**
- Activity
- Logout

The Master Contact can create additional system contacts who can use the system. He can even create another **Master Contact**. In our training document the procedure was not made clear.

Alarm User SLIDE 2 of 3

User ID 4

Pin 6131

Authority Level

<input checked="" type="checkbox"/> Master	<input checked="" type="checkbox"/> Installer	<input type="checkbox"/> Dealer
<input checked="" type="checkbox"/> System Test	<input type="checkbox"/> Edit Access Credentials	<input checked="" type="checkbox"/> Bypass Zones

Allowed Arming Levels

If you want to make someone a Master Contact you check "Master" as shown above. There is still something else you must do.

Contacts SLIDE 3 of 3 Test Notification Add Contact

Joseph Smith 903-407-4471	MASTER USER	ALARM USER	WEBSITE LOGIN	TEXT ALERT	EMAIL ALERT	TEST NOTIFY
Daniel Smith 903-407-4471	MASTER USER	ALARM USER	WEBSITE LOGIN	TEXT ALERT	EMAIL ALERT	TEST NOTIFY
Snap-IS Tech 903-407-4471	MASTER USER	ALARM USER	WEBSITE LOGIN	TEXT ALERT	EMAIL ALERT	TEST NOTIFY
Bill Jones 903-407-4471	MASTER USER	ALARM USER	WEBSITE LOGIN	TEXT ALERT	EMAIL ALERT	TEST NOTIFY

